




◀ T580A / T580 ▶

Item number	Description
-------------	-------------


- ① 5580-590A Seat Assy.
- ② AZ0800230A Wing Screw
- ③ AZ0800170A Wing Screw
- ④ 6700-095A Memory Lock for Tube dia. 22.2mm (0.9")
- ⑤ 5620-045 Rubber Foot (1pc)



◀ T560A / T560 ▶

Item number	Description
-------------	-------------

- ① 5560-590A Seat Assy.
- ② AZ0800230A Wing Screw
- ③ AZ0800170A Wing Screw
- ④ 6700-095A Memory Lock for Tube dia. 22.2mm (0.9")
- ⑤ 5620-045 Rubber Foot (1pc)



◀ T550A / T550 ▶

Item number	Description
-------------	-------------



- ① 5450-590A Seat Assy.
- ② AZ0800230A Wing Screw
- ③ AZ0800170A Wing Screw
- ④ 6600-095A Memory Lock for Tube dia. 25.4mm (1")
- ⑤ 1224-045 Rubber Foot (1pc)



◀ T350A / T350 ▶

Item number	Description
-------------	-------------

- ① 5450-590A Seat Assy.
- ② AZ0800230A Wing Screw
- ③ 6600-095A Memory Lock for Tube dia. 25.4mm(1")
- ④ AZ0800170A Wing Screw
- ⑤ 1123-045 Rubber Foot (1pc)



◀ T250A / T250 ▶

Item number	Description
-------------	-------------

- ① 5121-590A Seat Assy.
- ② ST060012035 Wing Screw (for Seat Assy.)
- ③ 5121-5010A Wing Screw
- ④ 3108-045 Rubber Foot (1pc)








- ◀ T560GA / T560G ▶
- ◀ T560GBA / T560GB ▶
- ◀ T560LA / T560L ▶

Item number	Description
-------------	-------------

- |   |            |   |
|---|------------|---|
| ① | 5563-590A  | Seat Assy. for T560GA                   |
| ② | 5568-590A  | Seat Assy. for T560GBA                  |
|   | 5565-590A  | Seat Assy. for T560LA                   |
| ③ | AZ0800230A | Wing Screw                              |
| ④ | AZ0800170A | Wing Screw                              |
| ⑤ | 6700-095A  | Memory Lock for Tube dia. 22.2mm (0.9") |
| ⑥ | 5620-045   | Rubber Foot (1pc)                       |



- ◀ T580GA / T580G ▶
- ◀ T580GBA / T580GB ▶
- ◀ T580LA / T580L ▶

Item number	Description
-------------	-------------

- |   |            |   |
|---|------------|---|
| ① | 5583-590A  | Seat Assy. for T580GA                   |
|   | 5588-590A  | Seat Assy. for T580GBA                  |
| ② | 5585-590A  | Seat Assy. for T580LA                   |
| ③ | AZ0800230A | Wing Screw                              |
| ④ | AZ0800170A | Wing Screw                              |
| ⑤ | 6700-095A  | Memory Lock for Tube dia. 22.2mm (0.9") |
| ⑥ | 5620-045   | Rubber Foot (1pc)                       |

